

MERLYN

# EASY-FIT

An innovative way to replace your bath screen without the need to re-drill the wall. Simply connect your easy-fit to the existing holes in the wall and install your new bath screen.

## Fitting Steps

Easy-Fit  
profile



1

REMOVE THE  
OLD PROFILE

2

POSITION THE  
EASY-FIT PROFILE  
ON THE WALL

3

ADJUST THE  
BRACKETS TO  
ALIGN TO THE  
EXISTING HOLES  
AND FIX IN  
POSITION



*Slide bracket  
up to align  
with hole*



Available with the MB1 / MB2 / MB3 / MB3A / MB3B and MB3C Bath Screens