




FITTING INSTRUCTIONS - CONCRETE FLOOR




*IMPORTANT INFORMATION - PLEASE READ FIRST

- This tray is made from natural materials. It is possible it may not be perfectly flat (approx 4mm in thickness) or may vary in thickness.
- Check the product thoroughly prior to fitting. Unfortunately no claims can be made once the tray has been installed.
- The tray must be fitted STRAIGHTLY with the installation instructions. Failure to do so and installing the product on the incorrect angle will void the guarantee and possibly lead to long term damage.
- The use of any membranes other than those specified in the fitting instructions could result in the shower tray to fail, invalidating the guarantee.
- Fit ONLY the waste slot supplied. Fitting any other waste will lead to a reduction in water flow.
- This shower tray and waste slot conform to British Standard EN704 approved for waste drainage. They are designed to provide a safe and effective waste outlet for your shower tray. Failure to do so will void the guarantee.
- For cleaning information refer to the 'Cleaning and Maintenance' section of the accompanying 'Information Pack'.
- If this product has been fitted as part of a wet room, see 12. If it has been fitted as part of an enclosure, see 13 for help with the location of the shower head and glass screens. This will help prevent unwanted waste in your enclosure.
- Do not allow any items such as flannels, sponges etc., to obstruct the waste slot during showering, this could lead to overflowing.


1 - STANDARD FIT - STEPS 1-6




4




7 - FLUSH FIT - STEPS 7-10




11 - OFF THE FLOOR PLINTH





12 - WET ROOM APPLICATION




5





6



7



8



9

13 - DOORS/SCREENS AND SHOWER HEADS

