

FITTING INSTRUCTIONS - WOOD FLOOR

STANDARD FIT

FLUSH FIT

WET ROOM

CONTENTS

*Important Information - See Below - Please Read First Prior to Installation

Standard Fit 1 - 6

Flush Fit 7 - 10

OT, The Floor Plinth 11

Wet Room 12

Doors/Screens And Shower Heads 13

STEPS

1 - 6

7 - 10

11

12

13

1 - STANDARD FIT - STEPS 1-6

1

Take care to avoid chipping or splitting adjacent areas when moving the tray into position.

Placing the tray in position, mark the floor boards by drawing around the tray. Mark out the center of the waste hole.

Move the tray to a safe location to prevent accidental damage.

2

Template supplied

It is recommended that a professional plumber completes the plumbing installation.

It is essential to use the template supplied to mark out the waste hole.

Use the floor boards to plank the waste and tray gap (Template and Waste Guide).

3

It is essential that the floor boards are properly secured, ensuring no movement or flex. Any joints in the floor boards that are not supported by a joist must be supported by separate noggins. Any floor boards that show flexing between joints MUST also be supported by additional noggins.

Ensure that floorboards under the waste hole are fully supported by noggins.

There must be no floor movement around the cut hole.

Fit the Effect floor area. Secure all the boards under the tray with two small screws at every joint. Dry out a night or a noggin.

4

Prior to mixing and cement, ensure the area. Ensure no gaps between floor boards. All gaps should be sealed with joint tape or caulk.

Mix sand and cement (6:1 ratio) putting self-compacting agent, such as 'Fibermix' and spread to fill within marked area with approximately 10-15mm mortar spread.

Ensure that the whole area under the tray is fully covered by the mortar spread. Any unspread area could lead to cracking.

5

24 HOURS DRYING TIME

Ensure to level the tray as all outer edges.

Apply a bead of silicone along the centre of each edge of the tray to be fitted against the walls.

Lay the tray in position, push against the wall and beat down into the mortar spread. Ensure all of the base is covered by the cement. Level the tray from each edge.

Leave for 24 hours prior to next step.

6

It is recommended a professional plumber completes the plumbing installation (see 13) - refer to Template and Waste Guide provided.

The waste down to the tray, leaving a 5mm gap between the tray and the pipe (G1).

Apply a bead of mould resistant silicone around between the floor and tray and along the back edge of the tray up to the bottom of the hole (see G6).

Finally, fit your chosen flooring (see appropriate and apply a bead of mould resistant silicone between the shower tray and your chosen floor (see 9 for guidance).

STANDARD FIT

FLUSH FIT

7 - FLUSH FIT - STEPS 7-10

Finally, install tray as per steps 1-6.

7

Screw down corner ply into the floor boards ensuring it is to the appropriate distance as the fitting fits flush with the edge of the tray. Apply silicone between the corner ply and tray, also approximately 1" along any joint that meets the tray edges.

8

Finish fitting ensuring a flush finish with the shower tray. Ensure that waterproof adhesive and grouting are used. Do not grout between the shower tray and adjacent tiles.

9

Ensure all edges are allowed properly.

Apply a bead of mould resistant silicone between the shower tray and adjacent tiles.

10

Waste cover is designed to be easily removed allowing access to waste trap.

Place the waste cover into the tray (do not use any adhesive).

Fit shower doors/screens and shower head as per diagram 13.

11 - OFF THE FLOOR PLINTH

12 - WET ROOM APPLICATION

***IMPORTANT INFORMATION - PLEASE READ FIRST**

- This tray is made from selected materials. It is possible it may not be perfectly flat upon close inspection or may show a 'breakline'. Check the product thoroughly prior to fitting. Unfortunately we cannot be responsible for any cracks once the tray has been installed.
- The tray must be fitted STRICTLY in accordance with the installation instructions. Failure to fit and maintain the product as per the instructions will invalidate the guarantee and possibly lead to long term damage.
- The use of any materials other than those specified in the fitting instructions could result in the shower tray to fail, invalidating the guarantee.
- IF ONLY the waste will be supplied, fitting any other waste will may lead to a reduction in water flow.
- The shower tray and waste will comply to achieve European EN124 approval for water drainage. They are designed to provide a water flow of over 20 litres per minute. Failure to fit the waste will provided easily in accordance with the fitting instructions (see contained within the 'Reference Pack') may reduce water flow and create drainage problems.
- Any cleaning intervention other than the 'Cleaning and Maintenance' section of the accompanying 'Reference Pack'.
- There should be no movement of any sections unless according to the tray (see Fig 3 - Mobile floor installation). Any movement should be prevented by adding noggins between floor joists when necessary. Any movement beneath the tray will eventually lead to cracking and will invalidate the guarantee.
- If the product has been fitted as part of a wet room, see 12. If it has been fitted as part of an enclosure, see 13 for help with the location of the shower head and glass screens. This will help prevent unwanted wet areas in your bathroom.
- Do not allow any items such as towels, soap etc., to obstruct the waste cover during operation. We could lead to overflowing.

11 - OFF THE FLOOR PLINTH

For more professional plumbing situations, a comprehensive 'Fitting Kit' is available. This covers the key all of the floor to provide a single plumbing solution. For further details, see your retailer or installer.

12 - WET ROOM APPLICATION

Instructions 1-11 cover all showering applications which include a shower door or screen.

If your tray has been purchased to be fitted as part of a wet room area with no surrounding glass, the following instructions apply:

Fit your tray in accordance with the 'Standard Fit' instructions (above steps 1-10) and in conjunction, incorporate a proprietary wall-fixing system.

See your retailer/installer for full details.

13 - DOORS/SCREENS AND SHOWER HEADS

Always fit a door or screen unless fitting as part of a wet room - See fig 1 and refer to section 12.

Screen fit a shower head at the open end of an enclosure - See figs 2/3/6

When fitting a wall in front screens only, ensure that the screen is correctly seated and approximately 1/2" the length of the tray - See fig 2

If fitting a side screen or the tray is adjacent to a wall, ensure that front points in at least approximately 2/3 the length of tray - See fig 2 or 6

Always fit a front screen unless fitting as part of a wet room - See fig 5 or 6

Always fit full enclosures to 900x900 square and 900 standard trays - See fig 4/6

Wast Shower Head Shower Door/Screen

Fig 1 - No Panel Enclosure

Fig 2 - Walk In - Front & Side Panel

Fig 3 - Walk In - Corner Panel

Fig 4 - Square - Full Enclosure Only

Fig 5 - Two End Panels

Fig 6 - Walk In - Front Panel

Fig 7 - Door Enclosure

Fig 8 - Quadrant - Full Enclosure Only